




Part #	Description
WFO 1401	30.75" x 16" Universal Aluminum Basket

10076 Streeter Road Suite #7, Auburn, CA 95602 Phone: 530.268.9494 www.wfoconcepts.com


### **WFO 1401**

BILL OF MATERIALS		
C-40001-01	Main Basket	Qty. 1
C-40001-02	Side Bolt Cap 1 Of 2	Qty. 2
C-40001-03	Side Bolt Cap 2 of 2	Qty. 2
33-6212	1/4"-20 x 3/4" SS Button Head Bolts	Qty. 4
33-23640	1/4"-20 SS Nylock Nut w/ Wax	Qty. 4
33-3041	1/4" SS Flat Washers	Qty. 16
33-6208	1/4"-20 x 1/2" SS Button Head Bolts	Qty. 16
8030T16	Strap Hold Down Mount	Qty. 2



5/32" Allen Socket 3/8" Drive Ratchet 7/16" Wrench

Anti-Seize




## WARNING!

- \*\*\* Read all instructions thoroughly from start to finish before beginning the job! If these instructions are not properly followed, severe frame, suspension, tire, or body damage may result to the vehicle!
  - \*\*\* WFO Concepts recommends that you exercise extreme caution when working under vehicles supported by jack stands.
- \*\*\* WFO Concepts recommends all installation to be performed by a professional shop/service technician. Product failure due to improper installation will not be covered under WFO's warranty policy.

## **TECH NOTES:**


- Whenever installing Stainless Steel Hardware it's a good idea to use Anti Seize to preventing galling of the threads.
- The corner ¼"-20 Penn Nuts have a max torque rating of 78 in. lbs. (6.5 ft. lbs.)





## **ASSEMBLY:**


1. Locate the 4 provided Corner Caps. Fig. A. There will be 2 oval shaped caps and 2 "bottle opener" shaped caps. These caps are universal per corner, it's up to the end user on which orientation they choose.

Fig. A











- 2. Locate the qty. (16) provided ¼"-20 x ½" SS Button head allen bolts and qty. (16) ¼" Washers.
- 3. Insert bolt through washer and into the pressed in Penn nut in the main basket. Fig. B. Repeat for all 16 bolts. Using a 5/32" allen socket and ratchet, snugly tighten all bolts.

\*Note – It's beneficial to add a little anti seize to any Stainless-Steel Hardware to prevent galling of the threads.



4. Next locate the qty. (2) ice chest hold down straps, qty. (4) 1/2"-20 x 5/8" SS allen bolts, and qty. (4) 1/2"-20 nylock nuts. Assemble with the hold down strap on the bottom of the basket. See Fig. C





10076 Streeter Road Suite #7, Auburn, CA 95602 Phone: 530.268.9494 www.wfoconcepts.com

# Follow us on all Social Media Platforms! Remember to share your photos and tag #WFOCONCEPTS to be featured on our page!





