



Part #	Description
WFO TB-3202	2020+ Jeep JT Rear HD Track Bar

10076 Streeter Road Suite #7, Auburn, CA 95602
Phone: 530.268.9494 www.wfoconcepts.com

WFO TB-3202

BILL OF MATERIALS	
WFO TB-3202	Track Bar Tube
FK JMXL14T-770	7/8" x 7/8"-14 Heim
WFO 5040	7/8" to 14MM Misalignment
M8501002-BK	3/8" Wobble Stopper Bushing
M8501004-BK	1/4" Wobble Stopper Bushing
TOOLS NEEDED	
Jack and Jack Stands	
Metric Socket Set: 21mm	
Metric Wrench Set: 24mm	
Pry Bar	
Impact gun	
Torque Wrench	



WARNING!

*** Read all instructions thoroughly from start to finish before beginning the job! If these instructions are not properly followed, severe frame, suspension, tire, or body damage may result to the vehicle!
*** WFO Concepts recommends that you exercise extreme caution when working under vehicles supported by jack stands.
*** WFO Concepts recommends all installation to be performed by a professional shop/service technician. Product failure due to improper installation will not be covered under WFO's warranty policy.
*** Whenever altering steering and suspension components it is always recommended to get a professional alignment afterwards ***

TECH NOTES:

- This kit will fit 2020+ 3.6L V6 and the 3.0L Eco Turbo Diesel
- You will be able to fit a max spare tire size of 37" (Tire manufacturers vary so double check before proceeding)
- WFO Suspension Components should be installed on a well-supported vehicle. Either supported by using appropriately rated jack stands under the front and rear frame rails OR by using an automotive lift.
- This kit retains some of the factory jeep hardware, keep all parts till the end.

REMOVAL:

1. Support Jeep with jack stands under the frame rails just in front of the rear tires. Also support the axle with a floor jack. It will be easier to use a floor jack so you are able to raise and lower the axle to free up the track bar hardware.
2. Using an impact gun with a 21mm socket and a 24mm wrench loosen and remove the upper track bar bolt.
3. Remove the lower track bar bolt also with the 21mm socket. The nut is a flag nut so you will not need a wrench.

INSTALL:

1. Be sure that when cutting the zip ties on both ends of your new track bar that the spacers and wobble stoppers stay in those positions. All 4 misalignment spacers are the same and can be interchangeable from top to bottom if they do fall out.
2. For the rubber Wobble Stoppers make sure that the thicker of the 2 bushings goes on the rear side of the uni-ball, snap ring side. The thinner, $\frac{1}{4}$ " thick, bushing goes on the front side when installing, flanged side.
3. Initially set the track bar to a length of 34". Depending on height of lift kit this is a good starting point.
4. Slide the welded uni-ball end with the spacers and wobble stoppers into the axle side track bar bracket, making sure that the bend goes towards the **FRONT** of the vehicle. Install with the factory bolt and nut, leave loose. **Fig A**
5. Install the heim end into the frame side track bar bracket, use the factory hardware and nut, leave loose for now. **Fig B**
6. **Always get a professional alignment after any suspension modifications.** But to get you close, set the Jeep back onto the ground on its own weight. Using a straight edge like a 4' level and a tape measure, set the level on the outside of the tire and measure to a solid point on the frame. Using the same technique, repeat on the other side. Adjust accordingly.
7. Be sure to use Blue Lock tight and tighten all factory hardware to a Torque of 100 ft. lbs. Tighten upper jam nut once set, making sure the heim is orientated straight up and down.

Fig A






Fig B



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.	Rev
1	WMA-13002	2019+ Jeep Gladiator - Rear Track Bar	1	A
2	JWXR14T-770	FK HD 3-Piece Precision Alloy Steel, PTFE Lined Helm - 7/8" x 7/8" RH	1	A
3	AN14T-770	AN14T-770 Assembly	1	A
4	WFO JN0875-14R	7/8"-14 Right Hand Jam Nut	1	A
5	59142-05-50	Internal Retaining Ring for FK AN14T-770	1	A
6	WFO 50-40	Straight Spacer - 7/8" to 14mm Bolt x 1.6" Stack Height	4	A
7	W8501002-BK	1" ID / 1.5" OD x 3.8" Wobble Stopper Bushing	1	A
8	W8501004-BK	1" ID / 1.5" OD x 1.4" Wobble Stopper Bushing	1	A

REV.		DESCRIPTION		DATE	APPROVED
A		Part Released		5/24/2022	KEVEN K



DRAWN BY:	KEVEN K	DATE:	5/24/22	MATERIAL:	DOM 1.5" x 25"	WFO CONCEPTS	10076 Streetler Rd. - Suite 7 Auburn, CA 95002 Phone: 530-268-9494 WWW.WFOCONCEPTS.COM
DRAWING UPDATED:				FINISH:	PC - SPEEDWAY BLACK		
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF WFO CONCEPTS. ANY REPRODUCTION, IN PART OR AS A WHOLE, WITHOUT THE WRITTEN PERMISSION OF WFO IS PROHIBITED.		TOLERANCES / DIMENSIONS ARE IN INCHES EXCEPT AS NOTED:		ANGULAR ±0.1°	BEND ±0.5°	TITLE: 2019+ Jeep Gladiator - Rear Track Bar	
DEC: 2PL ±0.01		DE: PL ±0.05	DO NOT SCALE DRAWING	SHEET 1 OF 1	PART # WFO-TB-3202	REV A	



10076 Streeter Road Suite #7, Auburn, CA 95602

Phone: 530.268.9494 www.wfoconcepts.com

Follow us on all Social Media Platforms!

Remember to share your photos and tag #WFOCONCEPTS to be featured on our page!

