



INSTALLATION INSTRUCTIONS

Part #	Description
WFO 2121	05-15 Toyota Tacoma Steering Wall Column Plate

10076 Streeter Road Suite #7, Auburn, CA 95602
Phone: 530.268.9494 www.wfoconcepts.com

WFO 2121 INSTALL INSTRUCTIONS

BILL OF MATERIALS

Qty. 1 – WM-39007	Firewall Plate
Qty. 1 – AS1000NP	Column Grommet

TOOLS NEEDED

Metric Socket Set and Ratchet
Hammer or dead blow
Air Saw / Hole Saw / Or Grinder
Black Spray Paint



WARNING!

- *** Read all instructions thoroughly from start to finish before beginning the job! If these instructions are not properly followed, severe frame, suspension, tire, or body damage may result to the vehicle!
- *** WFO Concepts recommends that you exercise extreme caution when working under vehicles supported by jack stands.
- *** WFO Concepts recommends all installation to be performed by a professional shop/service technician. Product failure due to improper installation will not be covered under WFO's warranty policy.
- *** Whenever altering steering and suspension components it is always recommended to get a professional alignment afterwards ***

TECH NOTES:

- This Firewall plate is intended for aftermarket columns only. Factory steering shafts will not work with this plate.
- This plate will work with WFO's location for the Trail Gear steering box as well as the PSC steering box using WFO's frame plates.
- The seal is intended for the 1" side of the DD shaft to fit through.

REMOVAL:

1. Installation is much easier to do before the coilover towers are installed.
2. From the inside of the cab, remove the rag joint from the column. **Remember to not let the steering wheel or column free spin or rotate too far.** Make sure the column is locked and the key removed before removing the steering column. Over rotating can break the internal clock spring for the blinkers, airbag, and horn. After the rag joint is loose from the top side of the column, slip the shaft out through the engine bay.
3. Remove the factory column mount plate off the firewall, there are Qty. (4) M6 bolts.

INSTALL:

4. Locate the new firewall plate. Some trimming to the firewall will be needed. Hold the plate up, aligned with the bolt holes, and mark where you will need to trim. An air saw will make quick work of this.



5. Once trimmed enough, smooth any edges and paint your firewall plate. Locate the seal and install it with the lip of the seal facing towards the engine. Lightly set in place with a hammer or dead blow, making sure it's flushed all the way around.



6. Install onto the firewall, you will use the previously removed bolts and bolt it into place, only 3 of the 4 holes will be used.
7. Proceed with installing the steering column from the wheel down the box.



10076 Streeter Road Suite #7, Auburn, CA 95602

Phone: 530.268.9494 www.wfoconcepts.com

Follow us on all Social Media Platforms!

Remember to share your photos and tag #WFOCONCEPTS to be featured on our page!

